

NOTE:

WHERE THE DECK IS NOT SUPPORTED BY AND FASTENED TO THE CONCRETE, VERTICAL WOOD NAILERS ARE REQUIRED AND SHOULD BE SECURED TO THE WALL WITH SUITABLE FASTENERS.

DERBIGUM®
MAKING BUILDINGS SMART

	P-3 WALL/SURFACE MOUNTED COUNTERFLASHING				DETAIL NO.
0		DRW	CHK	REV	P-3 SD
RT	DERBIGUM AMERICAS, INC. WWW.DERBIGUM.US	JS	LC	0.1	NOT TO SCALE